



Shelby Emergency Brake Handle Cover

Installation Instructions - S10M-2760-U

Application: 2010+ Ford & Shelby Mustangs

Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included) prior to starting installation. Vehicle should be off with key removed from ignition and in park with parking brake set prior to beginning installation. Expected installation time is 5 minutes.

Kit Contents	Description	Qty
	Emergency Brake Handle Cover	1

NOTES:

Read All Instructions Before Beginning Installation

Tools needed:

Allen Wrench (included)

Safety Glasses (please wear at all times during installation)



To place an order, or for current pricing, call Shelby Performance Parts. For a list of availability or for any other questions about Shelby Performance Parts or our products, visit ShelbyPerformanceParts.com or call our customer service department toll free:

1.702.405.3500 Mon-Fri 8:00 a.m. to 4:30 p.m. - PST

6755 Speedway Blvd
Las Vegas, NV 89115

t: 1.702.405.3500

Satisfaction Guarantee

If you are not happy with this product for any reason or found product to be defective in manufacturing, simply return it to Shelby Performance Parts, Inc. within 30 days of purchase and we will replace it – no questions asked. We stand behind our products one hundred percent, so you can sit behind in the wheel with pride.

**YOU MUST call Shelby Performance parts Customer Service for a Return Authorization (RA) before returning any product. Proof of purchase and dated receipt must be present with any return. All returned products are tested and if found to be damaged by the installer, no replacement will be issued. You pay the cost to ship to us, we pay for the return shipping. Guarantee does not include any labor and/or tax charges.*



Shelby Emergency Brake Handle

Installation Instructions

Information & Installation Instructions

Step 1: Turn key to the off position and remove from ignition, making sure vehicle is in park / neutral and the parking brake is set on a flat, level surface.

Step 2: Slide new cover over existing E-Brake, being careful not to accidentally release brake. Flat end goes toward the back, with radius end toward the front, and set screws to the bottom. Use included Allen wrench to tighten set screws snug in bottom, but over-tightening is not required and will just dig into handle. Set screws may need to be backed out slightly for installation, as they are fully threaded into holes. A small amount of soapy water on the stock handle may assist in sliding the handle into place if the fit is tight.

Step 3: Enjoy your new E-Brake!